

SSS Clean Tread™ Installation Instructions

KADEE
INDUSTRIES, INC.

Model: Entec-58

7160 Krick Rd., Walton Hills, OH 44146
800-321-3827 - Tel 440-439-8650 - Fax 440-439-6889

INSTALLATION INSTRUCTIONS - STAINLESS STEEL GRATING AND FRAMES

The installation of grating with or without an aluminum frame is relatively simple. However, attention to detail can make the difference between a firm, well-installed grating, or one that appears loose, spongy, and could rattle.

UNCRATING UNITS

1. Check all grating boxes per packing slip:
 - Correct number of units and frames (if applicable).
 - Shop drawing.
 - Hardware package.
2. Check all merchandise for damage (*If damaged, report freight claim immediately- DO NOT REMOVE FROM CRATE until adjuster verifies*).
3. Grating panels will be shipped in their corresponding frame (if applicable).

INSTALLATION OF FRAMES *If no frames were provided skip to "Installation of Grating"*

The installation of the frame is a simple operation. However, care must be taken to avoid warping and/or bending of the steel angles or aluminum extrusions.

1. Install 4" grouting straps into the threaded channel located on the outside of the frame (the channel located on the underside of the frame may be used also) on 2' centers. Bend straps as needed. By following the markings on each frame section, fasten the frame sections together with the hardware provided
2. Ensure the frames are adequately blocked.
 - This will prevent the pressure of wet concrete or grouting cement from pushing in the sides of the frame.
 - Because the grating and frame tolerances are $-1/8"$, $+0$, warping of $1/4"$ could cause misfit or misalignment of the lockdowns and tapped holes for the lockdown bolts.
3. Place frame into opening and shim as required, allowing for a co-planer installation between the between the grating and the *finished* floor surface.
4. Pour in grouting cement around edges in a quantity that will be sufficient enough to be level with the inside edge of the perimeter frame.
 - Be sure to keep the top of the perimeter frame free of the cement.
 - *NOTE: The recess floor must be flat and level to ensure proper installation.*
5. Before cement is set, confirm dimensions per the enclosed drawings.
6. Set lead anchors for the locking devices:
 - Lay grating panel(s) into recess. *NOTE: For multi-panel units, be sure the panels are laid out in the proper configuration (as shown on the enclosed drawing). The panels are marked accordingly.*
 - Mark the location of the locking devices.
 - Remove grating and drill holes in concrete for the lead anchors.
 - Install anchors into hole; epoxy may be used to help ensure that the anchors hold in place.
8. After the cement has hardened, an insert (such as plywood) should be placed in the opening to protect the frame edges.

INSTALLATION OF THE GRATING (with frame)

1. Lay grating panel(s) into frame and align all lockdowns.
2. For multi-panel units, be sure the panels are laid out in the proper configuration (as shown on the enclosed drawing). The panels are marked accordingly.
3. Using the Allen Wrench provided, tighten firmly, but not completely.
 - At the completion of tightening the last lockdown, repeat the procedure (much like tightening the lug nuts on a tire). This will remove any slack or warping caused by uneven initial tightening.
 - With multiple panel units, variance within the "on center" parameters may cause some surface wires and support rods not to align with adjacent panels.
 - If the floor of the recess is flat and level then the grating will fit tightly onto the recess floor with minimal rattling or deflection.
4. After installation, inspect the grating regularly to ensure that all the lockdown bolts are tight, and the grating is level (co-planer with adjoining floor) and obstruction-free. Refer to Kadee Maintenance Instructions included in this packet.

INSTALLATION OF THE GRATING (without frame)

1. Pour slab to a depth to allow for installation co-planer to the adjoining floor.
2. Set lead anchors for the locking devices:
 - Lay grating panel(s) into recess. *NOTE: For multi-panel units, be sure the panels are laid out in the proper configuration (as shown on the enclosed drawing). The panels are marked accordingly.*
 - Mark the location of the locking devices.
 - Remove grating and drill holes in concrete for the lead anchors.
 - Install anchors into holes; epoxy may be used to help ensure that the anchors hold in place.
3. Lay grating panel(s) into opening and align all lockdown holes with the lead anchors.
4. Using the Allen Wrench provided, tighten firmly, but not completely.
 - At the completion of tightening the last lockdown, repeat the procedure (much like tightening the lug nuts on a tire). This will remove any slack or warping caused by uneven initial tightening.
 - With multiple panel units, variance within the "on center" parameters may cause some surface wires and support rods not to align with adjacent panels.
 - If the floor of the recess is flat and level, then the grating will fit tightly onto the recess floor with minimal rattling or deflection.
5. After installation, inspect the grating regularly to ensure that all the lockdown bolts are tight, and the grating is level (co-planer with adjoining floor) and obstruction-free. Refer to Kadee Maintenance Instructions included in this packet.

USE ALL OF THE LOCKDOWNS PROVIDED.