

Hidden Lockdown Device Installation Instructions

Models: KD98, KD58, KD38



Refer to the attached drawing for assistance.

Determine the location of the lockdown clips according to the shop drawings enclosed with your shipment.

FIGURE #1: Hidden lockdown device

- Snap bolt centering clip spring on saddle clip.
- Place bolt into the bolt centering clip spring, thru the saddle clip.

FIGURE #2: Slide lockdown into grating panel

- Hold clip assembly between thumb and index forefinger and squeeze between support bars. If pliers are used, do not over-squeeze.
- Slide clip assembly upward toward underside of surface bars.

FIGURE #3: Attach lockdown to grating panel

- Continue to press upward, making certain that clip fingers enter the proper location between surface bars, until clip fingers seat over the support bars and "spring-snap into place.

FIGURE #4: Adjust bolt

- Center the bolts between the underside and between the two middle surface rods.

Hidden Lockdown Device Installation Instructions

Models: KD98, KD58, KD38



8333 Boyle Parkway, Twinsburg, Ohio 44087
800-321-3827 - info@kadeeindustries.com

