



HIDDEN LOCKDOWN DEVICE INSTALLATION INSTRUCTIONS

Models: KD98, KD58, KD38
Type: Hidden Lockdowns Devices, Only

Refer to the attached drawing for visual assistance.

To begin, determine the location of the lockdown clips according to the shop drawings that were enclosed with your shipment. These drawings provide the necessary positioning and layout for proper installation.

Start by snapping the bolt centering clip spring onto the saddle clip. Once the spring is in place, insert the bolt through the centering clip spring and the saddle clip. This forms the clip assembly, which will be inserted into the grating panel.

To install the clip assembly, hold it between your thumb and index finger, and squeeze it gently between the support bars. If you choose to use pliers, take care not to over-squeeze, as this could damage the components. While maintaining pressure, slide the clip assembly upward toward the underside of the surface bars.

Continue pressing the assembly upward, ensuring that the clip fingers enter the correct position between the surface bars. Push until the clip fingers seat firmly over the support bars and snap into place with a spring-like action.

Once the lockdown device is in place, adjust the bolt so that it is centered between the underside and the two middle surface rods. This ensures the lockdown is properly aligned and securely fastened.